



Caring for your Compact-Exterior tabletops:

Because of their thick, resilient and hygienic laminate surface, Compact-Exterior tabletops need no special cleaning and are generally easy to keep clean without the use of special cleaning products.

However, we recommend that you use this special **Compact-Exterior Protector** on your tabletops roughly 1–2 times a year.

If your tabletop is stained

To remove soiling or staining, whether slight or obstinate, it is important to use only gentle cleaning products, such as soapsuds. Furniture polishes and waxy cleaning substances must not be used, because the build-up forms a sticky coating that attracts dirt.

It is particularly important that any cleaning products used do not contain abrasive or corrosive substances as these can affect the shine, cause scratches or damage the tabletop surface.

Clean up any soiling and spills of tea, coffee, wine, etc. immediately: if left they become more difficult to remove.

Despite these precautions, the surface and edges of the tabletop may lose their shine over time and in some circumstances may start to turn grey or become slightly discoloured. To prevent this, the surface and edges of the tabletop can be treated and if necessary revived with the **Compact-Exterior Protector**.

Using the Protector (we recommend that you wear disposable gloves):

1. Clean the tabletop and edges thoroughly with a standard all-purpose domestic cleaning product or soapsuds, using lukewarm water and a soft cloth. Dry them well.
2. Apply a thin layer of the Protector to the tabletop: put a little of the gel-like Protector onto the dry polishing cloth and rub it evenly into the surface of the tabletop. Leave for about 5 minutes.
3. Remove the surplus Protector with a soft cloth to prevent it being transferred to clothing or other items.

This procedure can be carried out as often as necessary.

Fading and/or discolouring of the tabletop and edges do not constitute technical defects. The revival procedure is therefore not essential.